



RNAscope® Fluorescent Assay Sample Preparation for Fixed Frozen Tissue (Part 1)

Introduction

This Technical Note is for users who wish to run the RNAscope® Multiplex Fluorescent Assay (Cat. No. 320850) with fixed frozen tissues. The required RNAscope® Pretreat Reagents are Pretreat 2 (Cat. No. 320043) and Pretreat 4 (available in Cat. No. 320842). For the Part 2 procedures for the detection assay please refer to *RNAscope®*

Workflow

Part 1: Prepare the Tissue Sections

Fix Sample

1. If needed, perfuse tissue with freshly prepared 4% paraformaldehyde (PFA) in 1X PBS, or go directly to step 2.
2. Dissect tissue and place in freshly prepared 4% PFA for **24 HRS** at **4°C**.

Freeze Tissue

1. Immerse the tissue in 10% sucrose in 1X PBS at **4°C** until the tissue sinks to the bottom of the container (approximately 18 HRS for brain tissue).
2. Repeat this step with 20% sucrose in 1X PBS, followed by 30% sucrose in 1X PBS, each time allowing the tissue to sink to the bottom of the container.
3. Freeze the tissue in the Optimal Cutting Temperature (OCT) embedding media with dry ice or liquid nitrogen and store it in an airtight container at **-80°C**.

Prepare Sections

1. Before tissue sectioning, equilibrate the tissue blocks at **-20°C** for at least **1 HR** in a cryostat.

Fluorescent Multiplex Kit User Manual Part 2. Refer to the user manual for safety guidelines. For every chemical, read the Material Safety Data Sheet (MSDS) and follow handling instructions. For the latest services and support information, go to: www.acdbio.com/support

2. Section the blocks by cutting 7–15 µm sections. Mount the sections on SuperFrost® Plus slides (Fisher Scientific # 12-550-15).

IMPORTANT! Use only SuperFrost® Plus slides. Other slide types may result in tissue loss.

3. Air dry the slides for **20 MIN** at **-20°C**, or if slides are not used immediately, store the sections at **-80°C** for **< 3 MONTHS**.
4. Wash the slides with 200 mL 1X PBS in a Tissue-Tek® slide rack for **5 MIN** while moving the rack up and down to remove OCT.

Part 2: Tissue Pretreatment

Prepare Materials

1. Bring HybEZ™ Oven to **40°C**.
2. Place a wet humidifying paper in the Humidity Control Tray, leaving the HybEZ™ Slide Rack on bench. Re-insert the covered tray into the oven and close the oven door. The tray should be pre-warmed for at least **20 MIN** before use.
3. Prepare 700 mL fresh 1X Pretreat 2 in a beaker. Cover with foil, bring to a mild boil, and

TECHNICAL NOTE: Sample Prep

maintain uniform boiling at **99–100°C**. Do not boil more than **30 MIN** before use.

Apply Pretreat 2

1. With a pair of forceps *very slowly* submerge a slide rack containing the slides into boiling 1X Pretreat 2 solution for **5 MIN**.

Note: Depending on tissue type, boiling time may need to be adjusted.

2. *Immediately* transfer the hot slide rack to a staining dish containing distilled water.
3. Wash slides in distilled water by moving the rack up and down 3–5 times. Repeat with fresh distilled water.
4. Wash slides in fresh 100% EtOH by moving the rack up and down 3–5 times. Air dry.

Create Barrier

1. Draw 2–4 times around tissue using the Immedge™ hydrophobic barrier pen. Let the barrier dry completely **~1 MIN** or **OVERNIGHT** at **RT**.

Obtaining Support

For the latest services and support information, go to:
www.acdbio.com/support.

At the website, you can:

- Access telephone and fax numbers to contact Technical Support and Sales.
- Search through FAQs.
- Submit a question directly to Technical Support.

Apply Pretreat 4

1. Place the slides on the HybEZ™ Slide Rack, and add 2–4 drops Pretreat 4 to each section. Use enough solution to completely cover the sections.
2. Place the HybEZ™ Slide Rack in the pre-warmed HybEZ™ Humidity Control Tray. Seal tray and insert back into the HybEZ™ Oven. Incubate for **30 MIN** at **40°C**.
3. Place slides in a Tissue-Tek® Slide Rack submerged in distilled water.
4. Wash the slides by moving the rack up and down 3–5 times. Repeat with fresh distilled water.

IMPORTANT! Proceed to the RNAscope® protocol using the *RNAscope® Fluorescent Multiplex Kit User Manual Part 2* (Catalog No. 320293) available at www.acdbio.com/support/technical-doc

*Unlock your RNA with
RNAscope® Technology*

RNAscope® allows single-cell gene expression profiling *in situ*—unlocking the full potential of RNA biomarkers. The targeted molecular signature of every cell in a sample is revealed and measured precisely, all within the intricate cellular and tissue architecture of clinical specimens.

For Molecular Biology Applications (MBA), not intended for diagnosis. Refer to appropriate regulations.

NOTICE TO PURCHASER: PLEASE REFER TO THE RNASCOPE® 2.0 ASSAY- USER MANUAL FOR LIMITED USE LABEL LICENSE OR DISCLAIMER INFORMATION. Advanced Cell Diagnostics, Inc. reserves the right to change its products and services at any time to incorporate technological developments. This manual is subject to change without notice. Although this manual has been prepared with every precaution to ensure accuracy, Advanced Cell Diagnostics, Inc. assumes no liability for any errors, omissions, or for any damages resulting from the use of this information.

© 2014 Advanced Cell Diagnostics. All rights reserved. RNAscope® and HybEZ™ are trademarks of Advanced Cell Diagnostics, Inc. All other trademarks belong to their respective owners.

Headquarters

3960 Point Eden Way | Hayward, CA 94545 | Phone 1-510-576-8800 | Toll Free 1-877-576-3636

For support, email support@acdbio.com.

www.acdbio.com

